



3

Perform the in-app setup





Step 1

Follow the in-app setup process

In the Ring app, select the option to add a new device. When prompted, select **Video Doorbell Pro**, and follow the in-app instructions.



Step 2

Install the faceplate

Secure one of the faceplates with a security screw, using the star-shaped end of your Ring screwdriver.



Shared Users

To let family or friends answer live events and view recordings (if cloud recording is enabled), select Shared Users on the settings screen of the Ring app, and enter their email(s).



Motion Detection

Motion detection is disabled by default.

To enable and customize motion detection, select Motion Settings on the settings screen of the Ring app.



Cloud Video Recording

This optional feature saves events captured by your Ring Doorbell Pro.

You can view, download, and share these events on any device running the Ring app, or at: ring.com/activity



Live View

Select the **Live View** button on the settings screen of the Ring app to access a live stream of video from your Ring Doorbell Pro at any time.

Answering Your Door



When someone's at your door, or if motion is detected, you can perform the following actions:



Disable/enable your microphone



Zoom in/out



Mute/unmute sound in the app



Access the Ring Plus menu

RING ALERTS



MOTION ALERTS



You can toggle alerts for rings or motions on or off in the Ring app.



The front light on your Ring Doorbell Pro uses various patterns to communicate messages.

Here are a few that you might see:

In Setup Mode



White Spinning

Powered



White Solid

Front Button Pushed



Blue Spinning

Ring Speaker Enabled



Blue Solid

Updating Software



White Flashing



Ring Chime Setup

Plug your Chime in

First, simply attach the plug that matches your outlets, and plug your Chime in.

Once the light on the front is pulsing blue about once a second, your Chime is ready to be set up.

Ring Chime Setup

Follow the in-app prompts

Select “Set Up Device” on the homescreen of the Ring app, and follow the in-app instructions to set up your Chime.





Stick Up Cam

When used with Ring Doorbell, Stick Up Cam provides a Ring of Security around your home.

This self-install security system enables you to monitor and interact with anyone on your property, no matter where you are.

Learn more at:
ring.com/stickupcam

For additional help, visit: ring.com/help

For immediate assistance, we're available 7 days a week at: help@ring.com

US 1 800 656 1918

UK 01727 263045

AU 1 300 205 983

NZ +64 9 887 9871

Mexico (D.F) 52 55 8526 5445

Worldwide +1 310 929 7085

For a list of all our customer support numbers, visit: ring.com/callus



1523 26th St.
Santa Monica, CA 90404



Hereby, Bot Home Automation, declares that this consumer electronic is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at www.ring.com/DoC.pdf.

Protect the device from direct sunlight. Install the device at dry locations and protect it against rain and humidity. The device may not get contact to salt water or other conductive liquids. The device must be charged only within a building in a dry state.

Caution: Risk of explosion if battery is replaced by an incorrect type.

Dispose of used batteries according to the instructions.

© 2016 Bot Home Automation, Inc.

RING, ALWAYS HOME, and CHIME are trademarks of Bot Home Automation, Inc.

Last updated: 11/07/16